

AD 2.16 HELICOPTER LANDING AREA

1	<i>Coordinates TLOF or THR of FATO / Geoid undulation</i>	NIL INFO AVBL
2	<i>TLOF / FATO elevation (m/ft)</i>	NIL INFO AVBL
3	<i>TLOF and FATO area dimensions, surface, strength, marking</i>	NIL INFO AVBL
4	<i>True BRG of FATO</i>	NIL INFO AVBL
5	<i>Declared distance available</i>	NIL INFO AVBL
6	<i>APP and FATO lighting</i>	NIL INFO AVBL
7	<i>Remarks</i>	Main TWY

AD 2.17 ATS AIRSPACE

1	<i>Designation and lateral limits</i>	ATZ a) From a point at 254510S 0280600E on the Waterkloof CTR boundary. b) Thence east to a point at 254439S 0281152E. c) Thence south to a point at 255145S 0281214E. d) Thence west-southwest to a point at 255324S 0280729E on FAWK CTR. e) Thence north along the FAWK CTR back to the starting point at 254510S 0280600E.
2	<i>Vertical limits</i>	GND/7600 FT ALT
3	<i>Airspace classification</i>	Class C Class G airspace outside ATC hours of service.
4	<i>ATS unit call sign Language(s)</i>	Swartkop Tower English
5	<i>Transition altitude</i>	8000 FT
6	<i>Remarks</i>	NIL

AD 2.18 ATS COMMUNICATION FACILITIES

<i>Service designation</i>	<i>Call sign</i>	<i>Channel(s)</i>	<i>Hours of operation</i>	<i>Remarks</i>
1	2	3	4	5
Ground	Swartkop	121.75 MHz	On request only.	Pilots to follow unmanned procedures on 123.2 MHz outside TWR hours of service and to contact FAWK ATC on 124.1 MHz before entering and exiting FASK ATZ
Tower	Swartkop	123.2 MHz	MON-FRI: 0700-1300	

AD 2.19 RADIO NAVIGATION AND LANDING AIDS

Type of aid, MAG VAR, Type of supported OPS (for VOR/ILS/ MLS, give declination)	ID	Frequency	Hours of operation	Position of transmitting antenna coordinates	Elevation of DME transmitting antenna	Remarks
1	2	3	4	5	6	7
NIL	NIL	NIL	NIL	NIL	NIL	NIL

AD 2.20 LOCAL AERODROME REGULATIONS

1. Class B Compass swing: 2 x red circles marked on compass swing where pilots and technicians can stand. Be advised that the readings may be unreliable.
2. EV last Sunday of the month 0900-1500
RDO ,CTL flying taking place, GND - 7600FT AMSL.

AD 2.21 NOISE ABATEMENT PROCEDURES

Standard

AD 2.22 FLIGHT PROCEDURES

Outside hours of operation: All flights to contact FAWK TWR on frequency 124.1 MHz prior to entering FASK ATZ. Thereafter broadcast intentions on FASK ATZ Frequency 123.2 MHz maintaining a listening watch on FAWK TWR frequency.

AD 2.23 ADDITIONAL INFORMATION

- Prior permission required from the Chief of SANDF to utilize the aerodrome facilities.
- All MIL aerodromes are unlicensed, this aerodrome may not be nominated as an alternate destination for civilian flights. Diversion and landing in EMERG only.

AD 2.24 CHARTS RELATED TO AN AERODROME

NIL