

ENR (EN-ROUTE)
ENR 0
ENR 0.6 TABLE OF CONTENTS

ENR 0		
ENR 0.1	Preface - Not applicable	ENR 0.6 - 1
ENR 0.2	Record of AIP amendments - Not applicable	ENR 0.6 - 1
ENR 0.3	Record of AIP supplements - Not applicable	ENR 0.6 - 1
ENR 0.4	Checklist of AIP pages - Not applicable	ENR 0.6 - 1
ENR 0.5	List of hand amendments to the AIP - Not applicable	ENR 0.6 - 1
ENR 0.6	Table of contents to Part 2	ENR 0.6 - 1
ENR 1		
ENR 1.1	General Rules	ENR 1.1 - 1
	1 Minimum Heights	ENR 1.1 - 1
	2. Dropping objects, spraying or dusting	ENR 1.1 - 1
	3. Acrobatic flight	ENR 1.1 - 2
	4. Towing	ENR 1.1 - 2
	5. Times and Units of measurement	ENR 1.1 - 2
	6. Airspace Structure	ENR 1.1 - 3
	7. Prohibited Areas and flight restrictions	ENR 1.1 - 3
	8. Parasailing, kites, hang-gliders, and radio-controlled aircraft	ENR 1.1 - 3
ENR 1.2	Visual flight rules	ENR 1.2 - 1
	1. Visibility and distance from cloud	ENR 1.2 - 1
	2. Special VFR weather minima	ENR 1.2 - 3
	3. VFR flight determination and weather deterioration	ENR 1.2 - 4
ENR 1.3	Instrument flight rules	ENR 1.3 - 1
	1. Compliance with IFR	ENR 1.3 - 1
	2. Aircraft equipment	ENR 1.3 - 1
	3. Change from IFR flight to VFR flight	ENR 1.3 - 1
	4. IFR procedure	ENR 1.3 - 1
	5. Air Traffic service procedures	ENR 1.3 - 1
	6. Mandatory radio communication in controlled airspace	ENR 1.3 - 2
	7. Mandatory radio communication in advisory airspace	ENR 1.3 - 2
	8. Reporting position	ENR 1.3 - 3
	9. Performance based navigation	ENR 1.3 - 3
	10. Operational standards for inertial Navigation and reference systems	ENR 1.3 - 13

ENR 1.4	ATS airspace classification	ENR 1.4 - 1
	1.4.1 Classification of airspace	ENR 1.4 - 1
ENR 1.5	Holding, approach and departure procedures	ENR 1.5 - 1
	1. General	ENR 1.5 - 1
	2. Arriving Flights	ENR 1.5 - 1
	3. Cape Town INTL Airport	ENR 1.5 - 6
	4. King Shaka INTL Airport	ENR 1.5 - 10
	5. OR Tambo INTL Airport	ENR 1.5 - 15
	6. OR Tambo INTL Airport	ENR 1.5 - 18
	7. Departing flights	ENR 1.5 - 20
	8. Cape Town INTL Airport	ENR 1.5 - 26
	9. King Shaka INTL Airport	ENR 1.5 - 29
	10. O R Tambo INTL Airport	ENR 1.5 - 32
	11. O R Tambo INTL Airport	ENR 1.5 - 37
	12. Special procedures	ENR 1.5 - 40
ENR 1.6	ATS surveillance services and procedures	ENR 1.6 - 1
	1. Primary radar	ENR 1.6 - 1
	2. Secondary surveillance radar (SSR)	ENR 1.6 - 2
	3. Differences	ENR 1.6 - 7
	4. Graphic portrayal of area of radar coverage	ENR 1.6 - 7
	5. Promulgation of special rules applicable to radar separation and information	ENR 1.6 - 8
	6. Uniform implementation of 10 min longitudinal separation	ENR 1.6 - 8
	7. Radar Separation Assurance	ENR 1.6 - 9
ENR 1.7	Altimeter setting procedures	ENR 1.7 - 1
	1. Introduction	ENR 1.7 - 1
	2. Basic elements of the system	ENR 1.7 - 1
	3. Transition Altitude	ENR 1.7 - 2
	4. Transition Levels	ENR 1.7 - 4
	5. Application of procedures	ENR 1.7 - 4
	6. Enroute	ENR 1.7 - 4
	7. Approach and landing	ENR 1.7 - 5
	8. Missed Approach	ENR 1.7 - 6
	9. Description of altimeter setting region	ENR 1.7 - 6
	10. Procedures applicable to operators (including pilots)	ENR 1.7 - 6
	11. Semi-circular rule	ENR 1.7 - 7